

Tools Needed

- SLIP (soap and water) solution – Fill 1 spray-bottle with water. Add 5-7 drops of *BABY SHAMPOO*.
- TACK (alcohol and water) solution – Fill spray-bottle with 2/3 parts water and 1/3 part *70% ISOPROPYL RUBBING ALCOHOL*.
- Yellow squeegee – For use on installation. Supplied in install kit.
- Microfiber towel – For cleaning and drying areas of installation.

Tank

Center piece

1. Thoroughly clean tank with soap and water solution and microfiber towel.
2. Peel film off of the back liner while soaking the entire piece with slip solution.
3. Soak the tank with slip solution and align the film.
4. Spray a 2" line of tack solution on the bottom of the adhesive side of the film.
5. Soak top side of film with slip solution and remove any tack solution underneath the film using a squeegee.
6. Spray tack solution on the top line of the adhesive side of the film.
7. Stretch film in an upward motion until slack in the film has been stretched out.
8. Remove tack solution using squeegee.
9. Remove any excess slip solution using squeegee. (DO NOT SQUEEGEE SLIP SOLUTION INTO AREAS WHERE TACK SOLUTION HAS BEEN USED)
10. Dry the film with a microfiber towel and inspect for bubbles and seal the edges.

Side pieces (headlights and miscellaneous pieces use these instructions)

1. Thoroughly clean tank with soap and water solution and microfiber towel.
2. Peel film off of the back liner while soaking the entire piece with slip solution.
3. Soak the tank with slip solution and align the film.
4. Soak the topside of the film with slip solution.
5. Remove any slip solution underneath the film using a squeegee.
6. Dry the film using a microfiber towel .inspect for bubbles and seal the edges.

Fairings

1. Thoroughly clean tank with soap and water solution and microfiber towel.
2. Peel film off of the back liner while soaking the entire piece with slip solution.
3. Soak the tank with slip solution and align the film.
4. Starting in the center, spray tack solution on the adhesive side of the film.
5. Remove tack solution using a squeegee.
6. Apply tension in an outward motion, and remove any slip solution underneath the film using a squeegee. (TACK SOLUTION IS OPTIONAL ON THE OUTSIDE EDGES IF THE FILM DOES NOT ADHERE IMMEDIATELY)
7. Dry the film using a microfiber towel and inspect for bubbles and seal the edges.