

EPP Installation Instructions

Harley Davidson

1. Tools

- a) **Soap and water solution** – Fill 1 spray-bottle with water. Add 5-7 drops of BABY SHAMPOO.
- b) **Alcohol and water solution** – Fill spray-bottle with 2/3 parts water and 1/3 part 70% ISOPROPYL RUBBING ALCOHOL.
- c) **Yellow squeegee** – For use on installation.
- d) **Microfiber towel** – For cleaning and drying areas of installation.

2. Bag Tops

- a) Using SOAP AND WATER SOLUTION and MICROFIBER TOWEL, thoroughly clean the surface of the Bag Top area.
- b) Peel the film off the back liner while keeping the entire piece soaked with SOAP AND WATER SOLUTION.
- c) Soak the surface of the Bag Top area with SOAP AND WATER SOLUTION.
- d) Position and center the film on the surface of the Bag Top clearing all air pockets with your hands.
- e) Soak the top side of the film.
- f) Beginning in the CENTER, using the YELLOW SQUEEGEE, squeegee in an up/down motion, removing any solution under the film. (one spray of ALCOHOL AND WATER SOLUTION under the film, in the center, is optional)
- g) Remove remaining solution using the YELLOW SQUEEGEE from the CENTER-OUT using 3-5 inch, overlapping strokes.
- h) Repeat steps e-g.
- i) Dry the Bag Top area.
- j) Using the MICROFIBER TOWEL, dry edges of the film assuring the edges have adhered to the surface of the Bag Tops.
- k) Inspect for bubbles and lifting edges.

3. Gas Tank Protectors

- a) Remove Seat
- b) Using SOAP AND WATER SOLUTION and MICROFIBER TOWEL, thoroughly clean the surface of the Gas Tank area.
- c) Peel the film off the back liner while soaking the entire piece with SOAP AND WATER SOLUTION.
- d) Soak the surface of the Gas Tank with SOAP AND WATER SOLUTION.
- e) Position and center the film on the surface of the Gas Tank clearing all air pockets with your thumbs.
- f) Soak the top side of the film with SOAP AND WATER SOLUTION.

EPP Installation Instructions

Harley Davidson

- g)** Beginning on the **INSIDE**, using the *YELLOW SQUEEGEE*, squeegee in an up/down motion, removing any solution under the film. (one spray of *ALCOHOL AND WATER SOLUTION* under the film, in the center, is optional.)
 - h)** Stretch material in an **OUTWARD** motion, removing any excess material, using *ALCOHOL AND WATER SOLUTION* to lock material in place.
 - i)** Remove remaining solution using the *YELLOW SQUEEGEE*.
 - j)** Dry the Gas Tank area.
 - k)** Using the *MICROFIBER TOWEL*, dry edges of the film assuring the edges have adhered to the surface of the Gas Tank.
 - l)** Inspect for bubbles and lifting edges.
- 4. UNDER-SEAT**
- a)** Remove Seat
 - b)** Using *SOAP AND WATER SOLUTION* and *MICROFIBER TOWEL*, thoroughly clean the surface of the Under-Seat area.
 - c)** Peel the film off the back liner while soaking the entire piece with *SOAP AND WATER SOLUTION*.
 - d)** Soak the surface of the Under-Seat area with *SOAP AND WATER SOLUTION*.
 - e)** Position and center the film on the surface of the Under-Seat area clearing all air pockets with your hands.
 - f)** Soak the top side of the film with *SOAP AND WATER SOLUTION*.
 - g)** Beginning in the **INSIDE**, using the *YELLOW SQUEEGEE*, squeegee in an up/down motion, removing any solution under the film. (one spray of *ALCOHOL AND WATER SOLUTION* under the film, in the center, is optional.)
 - h)** Stretch material in an **OUTWARD** motion, removing any excess material, using *ALCOHOL AND WATER SOLUTION* to lock material in place.
 - i)** Remove remaining solution using the *YELLOW SQUEEGEE*.
 - j)** Dry the Under-Seat area.
 - k)** Using the *MICROFIBER TOWEL*, dry edges of the film assuring the edges have adhered to the surface of the motorcycle.
 - l)** Inspect for bubbles and lifting edges